

Solar-SNAP™

Radiant Heat Barrier

GARAGE DOOR KIT

INSTALLATION GUIDE

Kit Includes:

- 260 Square Feet of Radiant Barrier Material
- 1 roll of 4" HiBatt Tape

You will need:

- Eye Protection
- Gloves
- Tape Measure
- Straight Edge
- Cutting Surface
- Sharp Scissors or Utility Knife
- Common Foil HVAC Tape (May be required if using leftover from a partial kit)



PERFORMANCE NOTICE: Bonding surfaces must be clean, dust free and dry. Depending on pre-existing conditions, this may be as simple as dusting the surface with a clean towel or may require washing the door with soap and water.

To open material box - See label.



Step 1:

Clean Bonding Surface.

Step 2:

Measure each section of the garage door.

Step 3:

Measure and cut the material with a straight edge.

Step 4:

Install HiBatt Tape onto the inner side of door panel surface. Apply a square of tape to corners of each panel. Press firmly into place.

Step 5:

Remove backing from tape on one panel.

Step 6:

Center Radiant Barrier over door panel. It should overhang evenly over top and bottom of door panel. See picture to right.

Step 7:

Press in place at both ends.

Step 8:

Tuck material edge under the lip of the door panel.

Step 9:

Repeat steps 5-8 for each panel.



When safe to do so, it is helpful to partially open the door.



Some trimming and/or modification may be necessary.